
FLUID MANAGEMENT TECHNOLOGY

SMARTFILL GEN2

DOWNLOAD TRANSACTIONS VIA USB

Any USB drive may be used in a SmartFill Gen2.

The SmartFill Gen2 saves every transaction to local memory which may be retrieved by the export function incorporated into the unit. After retrieving the transactions to USB, they may be imported into the website using the website import function.

To export the transactions to USB do:

- Enter the Admin menu by:
 - Press and hold the <CLR> & <ENT> keys down together for a few seconds until the display reads “Enter admin or installer pin”
 - If it says anything else, press <CLR> to go back to the default display and try again.
 - Press <1>,<2>,<3>,<4>,<ENT>
- Once in the admin menu, press <8> for Import/Export
- Then <2> for Export
- Wait until the display reads “Done” and “Press any key to continue”
- Remove the USB

To import the transaction into the website:

- Login to your website
- Go to SmartFill Units page
- Use import function with USB drive inserted into computer

Note: From software version 1.07.08x onward, when you export the transactions to USB, each transaction will be marked as exported, so it will NOT be exported on any subsequent attempts. Therefore, the export function should only be used ONCE each time an export is required.